



www.avionteq.com


HHMPI CABLES, ACCESSORIES, & SOFTWARE



Flight Recorder P/N	Cable P/N	Description	Flight Recorder P/N	Cable P/N	Description
N/A	FDS40-0300	HHMPI Kit: Includes HHMPI Cradle and Case	Honeywell HFR5-D 980-4750-XXX	FDS40-0232	HFR5-D Interface Cable
N/A	FDS40-5102	HHMPI Engineering Unit Conversion Software		FDS40-5024	HFR5-D Download Software
N/A	FDS40-0331	HHMPI PCMCIA Assembly		Honeywell HFR5-V CVR 980-6032-001	FDS40-0247
N/A	FDS40-0332	Wireless Capability Option (V2 only)	FDS40-0274		HFR5-V Interface Cable. Requires CVR Adapter Cable for On-Wing Downloads
N/A	FDS40-0263	HHMPI Live Data Emulator (V2 only)	FDS40-5027		HFR5-V Download Software
N/A	FDS40-5103	HHMPI Encrypted Download Software (Customer Controlled Encryption)	FDS40-5033		HFR5-V Demultiplex Download Software (Optional)
N/A	FDS40-0373	HHMPI Docking Cradle	Smiths/GE VADR 3-Card, - 4Card	FDS40-0211	VADR Interface Cable (V2 only)
Flight Data Systems SENTRY FDS84-1001 FDR FDS84-3001 CVFDR FDS84-3101 CVFDR RIPS FDS84-2001 CVR FDS84-2101 CVR RIPS	FDS40-0283	FDR & CVR Download Interface Cable	Honeywell SSCVR 980-6020-XXX 980-6022-XXX	FDS40-0215	CVR Rack Adapter (On-Aircraft)
	FDS40-0068	Bench Power Cable		FDS40-0216	CVR Download and Power Interface Cable (On bench)
	FDS40-0069	Interface Cable (Bias/Aircraft Cable On-Wing) - (Optional)		FDS40-5020	SSCVR Download Software
	FDS40-5053	FDR Data Download Software		FDS40-5021	SSCVR Demultiplex Software Option
	FDS40-5054	CVR Data Download Software	L3Harris Micro QAR (L3 Communications)	FDS40-0241	USB Cable
		FDS40-5017		QAR Software	
Honeywell UFDR 980-4100-XXX	FDS40-0204	UFDR (Sunstrand DFDR) UFDR, Interface Cable	Honeywell DVDR 980-6025-001	FDS40-0227	DVDR, Interface Cable. Requires FDS40-0247 for (On-Aircraft) downloads
	FDS40-0275	UFDR (Sunstrand DFDR) UFDR, Interface Cable		FDS40-0247	ARINC-757 / HFR5-V CVR Rack Adapter. (On-Aircraft)
	FDS40-5025	UFDR Download Software		FDS40-5023	DVD-R CVFDR Download Software
Honeywell SSFDR 980-4710-00X	FDS40-0208	AR Series FDR Interface Cable	Honeywell AR 980-6021-032 CVR 980-6021-066 CVR 980-6021-072 CVFDR 980-6021-083 CVFDR 980-6023-XXX (AR-30 AR-120)	FDS40-0246	AR Series CVR/Combi Interface Cable (On-Aircraft)
	FDS40-5022	SSFDR Download Software		FDS40-5026	AR Combi CVFDR Download Software (Downloads Both)
Honeywell SSFDR 980-4120-XXX 980-4700-XXX	FDS40-0203	SSFDR Interface Cable		FDS40-5021	SSCVR Demultiplex Software (Optional)
	FDS40-5022	SSFDR Download Software	L3Harris FDR, CVR, CVDR FA2100 / FA2200 / FA2300	FDS40-0202	FA2100 Interface Cable Requires FDS40-0247 CVR Rack Adaptor (On-Aircraft)
Honeywell LW Series 980-4131-XXX FDR 980-6050-XXX CVR 980-6044-XXX CVDR	FDS40-0210	LW AR HFR5 Interface cable. Requires FDS40-0259 (On-Aircraft) CVR download		FDS40-0247	ARINC-757 CVR Rack Adaptor: Aircraft Rack Adapter (On-Aircraft)
	FDS40-0259	LW Power Cable (On-Aircraft)		FDS40-5011	FDR Download Software
	FDS40-0221	Extra Long 45ft Cable		FDS40-5012	CVR Download Software
	FDS40-5016	LW Download Software		FDS40-5013	L3 Wavefile Demultiplex Software (Optional)
L3Harris F1000 SSFDR S603 / S703 / S903 / S800	FDS40-0201	F1000, SSFDR Interface Cable			
	FDS40-5014	F1000 Download Software			

HHMPI CABLES, ACCESSORIES, & SOFTWARE



Flight Recorder P/N	Cable P/N	Description	Flight Recorder P/N	Cable P/N	Description
L3Harris A200S CVR S200-00XX-00	FDS40-0272	A200S CVR Interface Cable (on bench) Requires FDS40-0247 (On-Aircraft) Rack Adapter for downloads	L3Harris FA5000 FDR & CVR	FDS40-0223	FA5000 Interface Cable. Requires FDS40-0247 (On-Aircraft) CVR rack adapter
	FDS40-0274	ARINC-757 CVR Rack Adaptor. Aircraft Rack Adapter. (On-Aircraft)		FDS40-0247	ARINC-757 CVR Rack Adaptor. Aircraft Rack Adapter. (On-Aircraft)
	FDS40-5031	A200S CVR Download Software (Demultiplex software PN: 47-0197-00 and User Manual PN: 30-0073 supplied with the HHMPI kit on the USB)		FDS40-5015	FA5000 CVR & FDR Download Software
L3Harris SRVIVR 1493100-1XXXX CVR 1493100-2XXXX FDR 1493100-3XXX CVDR	FDS40-0209	SRVIVR Interface Cable. Requires FDS40-0259 (On-Aircraft) CVR Power cable	L3Harris FA5001 FDR & CVR	FDS40-0223	FA5001 Interface Cable Requires FDS40-0076 FA5001 Rack Adapter
	FDS40-0259	SRVIVR CVR Power Cable (On-Aircraft)		FDS40-0076	ARINC-757 CVR Rack Adaptor. Aircraft Rack Adapter. (On-Aircraft)
	FDS40-5016	SRVIVR Download Software		FDS40-5015	FA5001 CVR & FDR Download Software
Universal Avionics 1607 FDR 1606 CVR 1605 CVDR	FDS40-0224	UASC CVFDR Interface Cable. Requires FDS40-0258 (On-Aircraft) CVR Power cable (V2 Only)	BASE MCR 500-XXX SCR 500-XXX	FDS40-0212	MCR 500 / SCR 500 Interface Cable
	FDS40-0258	UASC 1605 1606 series CVR Download Power Cable (On-Aircraft)		FDS40-0269	MCR 500 / SCR 500 Passive Interface Cable (Alternate)
	FDS40-5030	UASC Download Software		FDS40-5040	BASE Download Software
Penny & Giles MPFR D51615-XXX	FDS40-0271	MPFR Bench Download Cable (Requires portable 28V dc PSU)			
	FDS40-5029	MPFR FDR Download Software			
	FDS40-5034	MPFR CVR Decompression Software (Optional)			
FDS40-5035	MPFR CVR Download Software				
Lockheed L209 10077A500-803 FDR	FDS40-0205	L209 / Plessey 1584 Interface Cable (V2 only)			

Proprietary and Confidential

This document contains proprietary and confidential information of Flight Data Systems. It is intended solely for the use of the individual or entity to whom it is addressed. Any unauthorized review, use, disclosure, or distribution is prohibited.

Parts list is subject to change at any time without notice. Contact sales@flightdata.aero for up-to-date information.

Flight Data Systems

AVIATION PRODUCTS & SERVICES FOR COMMERCIAL & MILITARY

Copyright © 2024 Flight Data Systems | HHMPI-ACCESS Revision 2024.07.08

Data, including specifications, contained within this document are summary in nature and subject to change at any time without notice at Flight Data Systems' discretion.

Call for latest revision. All brand names and product names referenced are trademarks, registered trademarks, or trade names of their respective holders.

